


Model No.DMR112 JOB SITE RADIO



Model No.DMR112 JOB SITE RADIO

| Numéro d'article | N ° de pièces | Description | Interchangeabilité | Q'ty | Nouvelle / ancienne | Note 1 | Note 2 |
|------------------|---------------|-------------------------|--------------------|------|---------------------|--------|--------|
| 001 | SE00000658 | PCB A ASS'Y | | 1 | * | | |
| 001-1 | SE00000658 | PCB A ASS'Y | < | 1 | * | | |
| 001-2 | SE00000825 | PCB A ASSEMBLY | O | 1 | | | |
| 002 | SE00000325 | SCREW PTB 3X8(NI) | | 8 | | | |
| 003 | SE09090011 | SCREW 1.7 | | 5 | | | |
| 004 | SE00000659 | POWER BUTTON HOLDER | | 1 | | | |
| 005 | SE09090011 | SCREW 1.7 | | 7 | | | |
| 006 | SE00000660 | PRESET BUTTON HOLDER | | 1 | | | |
| 007 | SE00000325 | SCREW PTB 3X8(NI) | | 4 | | | |
| 008 | SE00000656 | KNOB LENS HOLDER | | 1 | | | |
| 009 | SE00000661 | POWER BUTTON | | 1 | | | |
| 010 | SE00000662 | PRESET BUTTON | | 1 | | | |
| 011 | SE00000663 | PCB P ENCODER ASS'Y | | 1 | | | |
| 012 | SE09064161 | SCREW M4X16 | | 1 | | | |
| 013 | SE00000325 | SCREW PTB 3X8(NI) | | 4 | | | |
| 014 | SE09064161 | SCREW M4X16 | | 1 | | | |
| 015 | SE00000664 | FRONT CABINET ASS'Y(CE) | | 1 | | | |
| 016 | SE09064161 | SCREW M4X16 | | 1 | | | |
| 017 | SE00000325 | SCREW PTB 3X8(NI) | | 1 | | | |
| 018 | SE09064161 | SCREW M4X16 | | 1 | | | |
| 019 | SE00000666 | FRONT BUMPER | | 1 | | | |
| 020 | SE00000160 | SCREW PTHE6X47(CR) | | 4 | | | |
| 021 | SE0338PC5Z | FRONT BAR | | 2 | | | |
| 022 | SE00000355 | JACK RUBBER COVER | | 1 | | | |
| 023 | SE00000356 | JACK COVER | | 1 | | | |
| 024 | SE21B1110A | ROTARY KNOB RING | | 1 | | | |
| 025 | SE00000482 | ROTARY KNOB (BLK) | | 1 | | | |
| 026 | SE09176166 | HEX SCREW M6X16 | | 2 | | | |
| 027 | SE00000357 | BATTERY BUMPER | | 1 | | | |
| 028 | SE09176166 | HEX SCREW M6X16 | | 2 | | | |
| 029 | SE00000359 | REAR BUMPER | | 1 | | | |
| 030 | SE00000362 | LOCKER COVER | | 1 | | | |
| 031 | SE00000364 | LOCKER FIXER PIN 73.5MM | | 1 | | | |
| 032 | SE00000365 | LOCK HINGER | | 1 | | | |
| 033 | SE00000483 | BATTERY COVER | | 1 | | | |
| 034 | SE00000369 | LOCKER FIXER PIN 64.5MM | | 1 | | | |
| 035 | SE00000325 | SCREW PTB 3X8(NI) | | 2 | | | |
| 036 | SE00000371 | BATTERY COVER PACKING | | 1 | | | |
| 037 | SE00000176 | SCREW PTHE6X20(CR) | | 1 | | | |
| 038 | SE00000177 | HANDLE HOLDER(R) | | 1 | | | |
| 039 | SE00000179 | HANDLE | | 1 | | | |
| 040 | SE00000180 | HANDLE HOLDER (L) | | 1 | | | |
| 041 | SE00000176 | SCREW PTHE6X20(CR) | | 1 | | | |
| 042 | SE09176166 | HEX SCREW M6X16 | | 1 | | | |
| 043 | SE00000184 | SPRING | | 2 | | | |
| 044 | SE09994007 | STEEL BALL | | 2 | | | |
| 045 | SE00000445 | SCREW PTB 3X45(NI) | | 1 | | | |
| | | | | | | | |

| | | | | | | |
|-----|------------|--------------------------------|--|---|--|--|
| 046 | SE09994007 | STEEL BALL | | 2 | | |
| 047 | SE00000184 | SPRING | | 2 | | |
| 048 | SE09176166 | HEX SCREW M6X16 | | 1 | | |
| 049 | SE00000667 | REAR CABINET ASS'Y(CE) | | 1 | | |
| 050 | SE00000445 | SCREW PTB 3X45(NI) | | 1 | | |
| 051 | SE00000403 | DC RUBBER COVER | | 1 | | |
| 052 | SE00000404 | SCREW PTHE 3X14(CR) | | 1 | | |
| 053 | SE021PC030 | BATTERY COVER LOCKER | | 1 | | |
| 054 | SE00000669 | RUBBER ANT 88-108/174-240(BLK) | | 1 | | |
| 055 | SE00000398 | ROD ANT PACKING | | 1 | | |
| 056 | SE00000325 | SCREW PTB 3X8(NI) | | 1 | | |
| 057 | SE9076146A | HEX SCREW M6X14 | | 4 | | |
| 058 | SE024J9040 | PACKING | | 4 | | |
| 059 | SE00000408 | SPEAKER PANEL ASS'Y | | 1 | | |
| 060 | SE00000670 | SPEAKER RIGHT ASS'Y(Y) | | 1 | | |
| 061 | SE00000406 | SPEAKER PACKING | | 1 | | |
| 062 | SE00000416 | TERMINAL E (B) | | 1 | | |
| 063 | SE00000325 | SCREW PTB 3X8(NI) | | 2 | | |
| 064 | SE00000200 | TERMINAL C | | 1 | | |
| 065 | SE00000325 | SCREW PTB 3X8(NI) | | 2 | | |
| 066 | SE00000193 | SCREW 3X10 | | 2 | | |
| 067 | SE00000671 | PCB-B AUX IN 2 ASS'Y | | 1 | | |
| 068 | SE00000199 | SILICON RUBBER WASHER | | 1 | | |
| 069 | SE00000325 | SCREW PTB 3X8(NI) | | 1 | | |
| 070 | SE00000199 | SILICON RUBBER WASHER | | 1 | | |
| 071 | SE00000325 | SCREW PTB 3X8(NI) | | 1 | | |
| 072 | SE00000422 | SPEAKER HOLDER | | 1 | | |
| 073 | SE00000406 | SPEAKER PACKING | | 1 | | |
| 074 | SE00000672 | SPEAKER LEFT ASS'Y(W) | | 1 | | |
| 075 | SE00000408 | SPEAKER PANEL ASS'Y | | 1 | | |
| 076 | SE024J9040 | PACKING | | 4 | | |
| 077 | SE9076146A | HEX SCREW M6X14 | | 4 | | |
| 078 | SE00000430 | SWITCH KNOB | | 1 | | |
| 079 | SE00000673 | PCB D BATTERY SWITCH ASS'Y | | 1 | | |
| 080 | SE00000674 | PCB G UPDATE USB ASS'Y | | 1 | | |
| 081 | SE00000193 | SCREW 3X10 | | 2 | | |
| 082 | SE00000325 | SCREW PTB 3X8(NI) | | 2 | | |
| 083 | SE00000473 | TERMINAL 10.8V ASSY 011 WA1 | | 1 | | |
| 084 | SE00000325 | SCREW PTB 3X8(NI) | | 2 | | |
| 085 | SE00000675 | PCB F DC JACK ASS'Y | | 1 | | |
| 086 | SE09090011 | SCREW 1.7 | | 2 | | |
| 087 | SE00000435 | DC JACK HOLDER | | 1 | | |
| 088 | SE00000195 | W/TIES 100MM | | 3 | | |
| 089 | SE024PC040 | PACKING | | 1 | | |
| A01 | SE00000101 | AC ADAPTER | | 1 | | |

Veuillez indiquer les pièces n ° lorsque votre commande.

Date d'impression 06/06/2024