



Balkonschere

Gartenschere B/S

Gartenschere A/S

Gartenschere B/S-M

Gartenschere PremiumCut Trockenes Holz

Gartenschere PremiumCut Frisches Holz

Gartenschere PremiumCut Flex

Art.-Nr. 8707

Art.-Nr. 8854

Art.-Nr. 8855

Art.-Nr. 8857

Art.-Nr. 12240

Art.-Nr. 12241

Art.-Nr. 12242

Art.-Nr. 8855
Art.-Nr. 12240

